



Revision: 1.0 - 02/22/2010

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not fully understand the instructions prior to beginning the install.

**INCLUDED IN THE KIT:**

(1) Baron Comfort Kit (BA-7090-05)	(10) Chrome Caps
(4) Stainless Socket Set Screw	(4) M8 Stainless Cap Head Bolts
(4) 5/16" Stainless Shims	(4) 5/16" x1" Stainless Shoulder Bolts
(2) Black Powder Coated Baron Floorboard Mounts	(2) Chrome Baron Shortboards (solid or enferno)

**TOOLS REQUIRED:**

Pliers (std. and needle nose)	Phillips and Flat Screwdrivers
6mm Allen Wrench	3/32" & 5/32" Allen Wrenches
HD Shop Manual	

**INSTRUCTIONS:**

1. Lift the rubber on the stock passenger board and using a punch or small Phillips screwdriver, push the pins out that hold the board to the mount. Be careful not to lose the ball bearing & spring.
2. Remove stock passenger floorboard mount.
3. Follow instructions included with the Baron Comfort Kit. These are required when using the Baron Shortboards.
4. Using the M8 Stainless Cap Head Bolts, install the Baron Floorboard Mount onto the bottom of the board in the desired position (this position can be adjusted later if its not to your liking).
5. Once you are sure of the position, insert the Stainless socket set screw into each of the threaded holes.
6. Insert the spring into the hole on the factory floorboard mount. Replace the ball bearing on top of this spring making sure you do not lose it.
7. Insert the Baron Shortboard and Mount into the stock floorboard mount location. Secure with 5/16" x 1" Stainless shoulder bolts and blue Loctite. Make sure to use the stainless shims between the head of the bolt and the mount.
8. Make any adjustments to the board location.
9. Once the location is satisfactory, go over all bolts, making sure you tightened them to factory specifications.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.  
© 2013 Barons Custom Accessories