Revision: 6.4 - 01/02/2012
Install Time: 1 Hour

Please read ALL of the instructions BEFORE beginning the installation.

INCLUDED IN THE KIT:

(2) Baron Nasty Boy Mufflers	(1) 5/16 Zinc Lock Washer
(2) Pipe Clamps w/Hardware (27-56)	(1) 5/16-18 Nickel Cap Nut
(1) 5/16-18 Flat Head Socket Screw	(1) 04 Pipe Adapter Bracket

TOOLS REQUIRED:

6mm Allen Wrench, 10mm Socket	10mm End Wrench

INSTRUCTIONS:

IMPORTANT: Do not remove the OEM headpipes.

1. If possible, elevate the motorcycle and secure it solidly in place. Remove the OEM mufflers. Set these parts aside as they will no longer be needed.

2. Loosen rear header at the flange. (2-6mm allen heads)

3. Attach two new clamps (supplied) onto each of your new Nasty Boy mufflers. Finger tighten these bolts.

4. Slide the lower muffler onto the end of the lower headpipe. Install mounting bolt into support bracket, align muffler and headpipe and tighten mounting bolt (Leave clamps loose at this time).

5. Slide upper muffler on to loose headpipe, install mounting bolt in support bracket, align for proper appearance and tighten upper support mounting bolt.

6. Tighten rear cylinder header flange bolts.

7. Tighten all exhaust pipe clamps.

NOTE: We strongly recommend the application of Loctite®, or a similar material, on the threads of all bolts.

8. The air/fuel mixture should be adjusted for the change in exhaust flow and back pressure. For best results, a qualified technician should perform this procedure.

9. Re-tighten all bolts/nuts after riding 100 miles, including baffle retaining screw.

NOTE: For optimum performance, we suggest you install one of our Big Air Kits to increase horsepower and torque, improve acceleration and eliminate flat spots.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2013 Barons Custom Accessories

5221 Oceanus Drive • Huntington Beach, CA 92649 • (925)583-2499 - Ph. • (714)901-0520 - Fax • www.baronscustom.com • tech@baronscustom.com