STEALTH LICENSE & TURN SIGNAL MOUNT - Suzuki Boulevard M109

Revision: 2.4 - 02/10/2010
Install Time: 60 Minutes

Use Blue Loctite® on all hardware. Refer to owner's manual for any removal questions related to the stock assembly.

INCLUDED IN THE KIT:

Baron Powder-coated License Plate Holder	Stainless Hardware for Mounting Plate Frame
Chrome LED License Plate Frame	

TOOLS REQUIRED:

10mm Wrench/Socket	Wire Cutters/Strippers
4mm Allen wrench	Electrical Tape/Shrink Wrap
5mm Allen Wrench	Zip Ties

INSTRUCTIONS:

- This system is designed to work with stock turn signals, but you can substitute aftermarket signals like Baron Bullet Marker Lights (BA-3400-00) instead of using the stock signals.
- Installation is reasonably simple, providing you follow the instructions below implicitly.
- As always, please read the instructions in full prior to installing the product. If you feel you don't understand the instructions, please call our tech support line, or have the product installed by a competent technician.
- We strongly suggest that all connections be soldered and covered with shrink tubing for best results and longevity.

1. Remove front seat with the ignition key.
2. Remove 2 bolts holding the passenger pillion or rear cover.
3. Disconnect the white electrical connector going to the taillight and remove rear fender/taillight assembly.
4. Remove 4 bolts securing rear inner mudguard (this plastic inner fender holds your turn signals, license plate light and mount). NOTE: This will leave a space under the rear fender. It will not be seen.
5. Remove 2 bolts holding the silver bracket to the sub-frame. Unhook remaining electrical connections and remove mudguard/turn signal assembly.
6. Remove stock turn signals (if you plan to reuse them) from mudguard.
7. Using stock bolts from the silver bracket, install the license plate holder, bolting it on from underneath. We recommend using blue Loctite® on these bolts.
8. Install your stock turn signals (or other signals) in the license plate holder.
9. Install plate frame using supplied hardware (recessed allen head screws & lock nuts).
10. Run wires through the hole in center of plate mount.
11. Cut the white electrical connector off your stock license plate light. Be sure to leave as much slack as possible. It's easy to trim it to fit later.
12. Splice the wires into your new chrome LED license plate. White on plate to grey wire on connector and black on plate to black/white on connector (grey = positive, black/white = ground).
13. Be sure to zip-tie all wires up to prevent contact with rear tire.
14. Re-install the rear fender/taillight assembly and re-connect the white connector to the taillight.

Enjoy your new, Stealth License & Turn Signal Mount!

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2013 Barons Custom Accessories

5221 Oceanus Drive • Huntington Beach, CA 92649 • (925)583-2499 - Ph. • (714)901-0520 - Fax • www.baronscustom.com • tech@baronscustom.com