3.5" & 4" TRU-POWER CHROME SLIP-ON MUFFLER SET - 1995-2010 HARLEY DAVIDSON TOURING MODELS

Revision: 2.6 - 11/19/2009
Install Time: 45 minutes

CAUTION! We Strongly recommend that a qualified technician install this kit if you do not completely understand the instructions prior to the installation.

INCLUDED IN THE KIT:

(2) Tru-Power Chrome Slip-On Mufflers	(2) Exhaust Clamps

TOOLS REQUIRED:

9/16" & 1/2" Open End Wrenches	Red Loctite
1/2" & 9/16" Socket (optional)	Factory Service Manual (recommended)

INSTRUCTIONS:

1. Be sure motorcycle is properly secured before you begin.

2. Remove saddlebags and place aside.

3. Begin removing your stock mufflers. Starting on one side of the bike, loosen the clamp securing the muffler to the headpipe. Remove the two bolts securing the muffler to the mounting bracket on the saddlebag support of the bike. Keep these bolts for use with your new slip-on mufflers.

4. Using supplied clamp over new slip-on muffler install over stock headpipe. Align the mount tab with holes in the mounting bracket on the saddlebag support. Note that there is a left and a right side pipe. The clearance dent is on the side closest to the swingarm providing clearance on many models. Secure pipe with stock bolts. Be sure to apply Loctite® to bolts upon re-installation.

5. Securely tighten bolts, and then tighten the clamp securing the slip-on muffler to the headpipe.

6. On the opposite side of the bike, repeat steps 3-5.

7. Reinstall saddlebags.

8. Be sure to check proper alignment and clearances before riding.

9. Every time you perform regular maintenance be sure to re-torque all clamps and fasteners.

SUGGESTION: For maximum performance you can purchase our "Tru-Power" Headers and XXX Air Cleaner to truly complement the power that your new "Tru-Power" Slip-Ons provide.

DISCLAIMER: This aftermarket exhaust system is designed to replace a stock exhaust system on a motorcycle with its engine, frame, and other components in their stock design configuration and location. Re-mapping or re-jetting may be necessary after installation of these exhaust pipes.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. LA Choppers bears no responsibility on installation costs associated with this product.
© 2013 LA Choppers

5221 Oceanus Drive • Huntington Beach, CA 92649 • (925)583-2499 - Ph. • (714)901-0520 - Fax • www.lachoppers.com • tech@lachoppers.com